


Whirlpool WTW6600SG3 03 - MOTOR, BASKET AND TUB PARTS

MOTOR, BASKET AND TUB PARTS

For Models: WTW6600SW3, WTW6600SG3, WTW6600SB3
(White) (Biscuit) (Black)



W10172485

5

Whirlpool [Residential Whirlpool WTW6600SG3 Washer Parts](#) Parts Diagram 03 - MOTOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10106600			Cap, Impeller
2	W10076270			Screw And Washer Assembly
3	W10076260			Washer
4	W10130807			Tub Ring
5	8572540	353244		Hose, Pressure Switch
6	W10141017			Impeller
7	8533953			Screw, 8-16 X 1.000
8	W10118114	280145		Hub
9	8545953	280145		Hub
10	W10118182	W10296143		Basket
11	8572660	W10193886		Tub-Outer
12	W10137697			Harness, Lower
13	W10005430			Clamp, Pressure Hose Retainer
14	8533957			Screw, 10-16 X 1/2
15	W10137698			Shield, Drive Motor
16	8565172	280142		Tube

17	8565170	W10419333	Stator, Motor
18	8557836		Plate, Stator
19	8534042		Screw, 1/4-20 X .968
20	W10137685	W10178988	Rps Assembly
21	8565177	280146	Rotor
22	BLANK	Not Available	Bolt, Rotor Assembly Non-Serviceable (Supplied W/Rotor)
23	8566197	W10222008	Filter, Dual Pump Hood
24	8533928		Screw, 8-18 X 3/4

