


# Whirlpool WTW6700TW2 02 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Models: WTW6700TW2, WTW6700TU2  
(White) (Ultimate Silver)



W10243467

3

Whirlpool [Residential Whirlpool WTW6700TW2 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10200900</a>			Control Unit Assembly, Machine And Motor
2	<a href="#">W10130502</a>			Gasket, Valve Tray
3	<a href="#">8565304</a>			Tray Assembly, Console
"	<a href="#">W10158216</a>			Tray Assembly, Console
4	<a href="#">8565259</a>			Gasket, Console/Tray
5	W10128457	<a href="#">W10364988</a>		Valve
6	<a href="#">8574957</a>			Knob, Assembly
"	<a href="#">W10183632</a>			Knob, Control
7	<a href="#">W10051131</a>			User Interface
8	<a href="#">W10004990</a>			Screw, 6-20 X 1.2
9	<a href="#">W10110804</a>			Console
"	<a href="#">W10191904</a>			Console
10	<a href="#">8564265</a>			Cover, Rear- User Interface
11	<a href="#">W10003770</a>			Screw, 6-19 X 1/2
12	<a href="#">W10022060</a>			Nut, Push-In
13	<a href="#">W10128687</a>			Harness, Upper

14	<a href="#">8565324</a>		Screw, 10-16 X 1.75
15	<a href="#">8281136</a>		Screw, 10-16 X 3/4
16	<a href="#">3407203</a>		Cord Assembly, Power
17	<a href="#">98460</a>		Nut, Push-In
18	3976300	<a href="#">16123</a>	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
19	W10194208	<a href="#">89503</a>	Hose-Inlet
"	8571378	<a href="#">89503</a>	Hose-Inlet
20	<a href="#">3351614</a>		Screw, Gearcase Cover Mounting
21	<a href="#">3407187</a>		Harness, Thermistor

