


# Whirlpool WTW7800XB4 02 - CONTROL PANEL PARTS



Whirlpool [Residential Whirlpool WTW7800XB4 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">W10372179</a>			Control Unit Assembly, Machine And Motor
2	<a href="#">W10130502</a>			Gasket, Valve Tray
3	<a href="#">8578550</a>			Tray Assembly, Console
"	<a href="#">W10309224</a>			Tray Assembly, Console
"	<a href="#">W10309229</a>			Tray Assembly, Console
4	<a href="#">8546616</a>			Gasket, Console/Tray
5	<a href="#">W10326913</a>			Valve, Log Assembly W/Harness
6	<a href="#">W10211335</a>			Knob, Assembly
7	<a href="#">W10297399</a>			User Interface
8	<a href="#">W10052600</a>			Screw, 8-18 X 3/4
9	<a href="#">W10211348</a>			Console
"	<a href="#">W10211349</a>			Console
"	<a href="#">W10211350</a>			Console
10	<a href="#">3351614</a>			Screw, Gearcase Cover Mounting

11	<a href="#">98460</a>		Nut, Push-In
12	<a href="#">W10022060</a>		Nut, Push-In
13	<a href="#">W10350667</a>		Harness, Valve
14	<a href="#">8565324</a>		Screw, 10-16 X 1.75
15	<a href="#">8281136</a>		Screw, 10-16 X 3/4
16	<a href="#">3407203</a>		Cord Assembly, Power
17	W10242307	<a href="#">16123</a>	Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately.
18	W10194208	<a href="#">89503</a>	Hose-Inlet
"	W10194209	<a href="#">89503</a>	Hose-Inlet
19	<a href="#">W10346406</a>		Power Supply
20	<a href="#">9740849</a>		Screw, 8-18 X 7/16

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>