


Whirlpool WTW7800XL1 02 - CONTROL PANEL PARTS



Whirlpool Residential Whirlpool WTW7800XL1 Washer Parts Parts Diagram 02 - CONTROL PANEL PARTS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|--------|--------------------------------|
| 1 | W10327531 | W10384465 | | Control-Elec |
| 2 | W10130502 | | | Gasket, Valve Tray |
| 3 | 8578550 | | | Tray Assembly, Console |
| " | W10309224 | | | Tray Assembly, Console |
| " | W10309229 | | | Tray Assembly, Console |
| 4 | 8546616 | | | Gasket, Console/Tray |
| 5 | W10326915 | | | Valve, Log |
| 6 | W10211335 | | | Knob, Assembly |
| 7 | W10297399 | | | User Interface |
| 8 | W10052600 | | | Screw, 8-18 X 3/4 |
| 9 | W10211348 | | | Console |
| " | W10211349 | | | Console |
| " | W10211350 | | | Console |
| 10 | 3351614 | | | Screw, Gearcase Cover Mounting |
| 11 | 98460 | | | Nut, Push-In |
| 12 | W10022060 | | | Nut, Push-In |

| | | | |
|----|---------------------------|-----------------------|---|
| 13 | W10350667 | | Harness, Valve |
| 14 | 8565324 | | Screw, 10-16 X 1.75 |
| 15 | 8281136 | | Screw, 10-16 X 3/4 |
| 16 | 3407203 | | Cord Assembly, Power |
| 17 | W10242307 | 16123 | Washer Inlet-Hose Miscellaneous Parts Must be Ordered Separately. |
| 18 | W10194208 | 89503 | Hose-Inlet |
| " | 8571378 | 89503 | Hose-Inlet |
| 19 | W10346406 | | Power Supply |
| 20 | 9740849 | | Screw, 8-18 X 7/16 |

