


Whirlpool WTW7800XL2 01 - TOP AND CABINET PARTS



TOP AND CABINET PARTS

For Models: WTW7800XW2, WTW7800XB2, WTW7800XL2
(White) (Black) (Silver)

AUTOMATIC WASHER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

3-11 Litho in U.S.A. (MP)(bay)

1

Part No. W10407661 Rev. A

Whirlpool [Residential Whirlpool WTW7800XL2 Washer Parts](#) Parts Diagram 01 - TOP AND CABINET PARTS

[Click on the part number to view part](#)

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|---------------------------|---------------------------|---------------|--|
| 1 | W10240438 | | Not Available | Installation Instructions (English/French) |
| " | W10240439 | | Not Available | Installation Instructions (Spanish) |
| " | W10373818 | | Not Available | INSTALLATION INSTRUCTIONS (USE & CARE GUIDE) |
| " | W10338694 | | Not Available | INSTALLATION INSTRUCTIONS (TECH SHEET) |
| " | W10385943 | | Not Available | INSTALLATION INSTRUCTIONS (ENERGY GUIDE) |
| 2 | 3957177 | | | Top |
| " | W10298629 | | | Top |
| " | W10298630 | | | Top |
| 3 | W10162604 | W10198634 | | Frame |
| 4 | 8564017 | | | Cup, Suspension |
| 5 | 8566097 | W10434974 | | Cabinet |

| | | | |
|----|---------------------------|---------------------------|--------------------------------------|
| " | W10045598 | W10193869 | Cabinet |
| " | W10093798 | W10193880 | Cabinet |
| 6 | 8566090 | | Panel, Rear |
| 7 | W10160572 | | Retainer, Drain Hose Storage |
| 8 | W10155270 | | Cable Tie |
| 9 | W10111536 | W10198919 | Kit |
| 10 | W10237427 | W10247710 | Suspension |
| 11 | 1157158 | 489069 | Xxscrew, 10-12 X 1/2 |
| 12 | W10042120 | | Locator, Top |
| 13 | W10339706 | W10078270 | Screw, Lid Hinge Mounting |
| 14 | 8563965 | | Hinge Wire |
| " | 8572974 | | Hinge Wire |
| 15 | W10305275 | | Hinge, Spring Assembly |
| " | W10305276 | | Hinge, Spring Assembly |
| 16 | 8563785 | | Lock, Top- Front |
| 17 | 8546627 | | Bearing, Lid Hinge |
| 18 | W10177046 | | Cabinet - Damper, Sound |
| 19 | W10349235 | | Lid, Glass Assembly |
| " | W10349135 | | Lid, Glass Assembly |
| " | W10349136 | | Lid, Glass Assembly |
| 20 | W10240448 | | Foot Assembly, Leveling |
| 21 | W10172146 | | Dispenser, Fabric Softener |
| 22 | W10136371 | | Bezel, Fabric Softener Dispenser |
| " | W10306027 | | Bezel, Fabric Softener Dispenser |
| 23 | W10187307 | | Dispenser, Stain Remover |
| 24 | W10131523 | | Bezel, Stain Remover Dispenser |
| " | W10306029 | | Bezel, Stain Remover Dispenser |
| 25 | W10172154 | | Dispenser, Detergent |
| 26 | 8563877 | | Bezel, Detergent Dispenser |
| " | W10306028 | | Bezel, Detergent Dispenser |
| 27 | W10106990 | | Nozzle Assembly, Fresh Water |
| 28 | 371503 | 596669 | Clamp, Manifold |
| 29 | W10059230 | | Lock Assembly, Lid |
| 30 | 8572019 | | Bezel, Lid Lock |
| " | W10052520 | | Bezel, Lid Lock |
| " | W10143661 | | Bezel, Lid Lock |
| 31 | W10161707 | | Top Foam Seal |
| 32 | 8564456 | | Hinge, Top |
| 33 | 3390647 | 488729 | Screw |
| 34 | 343641 | 681414 | Screw, 10AB X 1/2 |
| 35 | 8563941 | | Cover, Harness |
| 36 | 693995 | | Screw, Hex Head |
| 37 | 8543784 | | Bracket, Drain Hose |
| 38 | W10167599 | W10198919 | Kit |
| 39 | 8281136 | | Screw, 10-16 X 3/4 |
| 40 | 8576476 | | Spacer, Rear |
| 41 | 370451 | 596669 | Clamp, Manifold |
| 42 | W10063340 | W10339879 | Tie, Cable |
| 43 | 3400061 | | Screw, Dispenser Housing Mounting |

| | | | |
|----|---------------------------|-------------------------|-----------------------------|
| 44 | 90016 | | Clip, Pressure Switch Hose |
| 45 | 8281736 | 3184020 | Wire |
| 46 | 3400076 | | Screw, Bracket Mounting |
| 47 | 8578386 | | Shield, Wire Harness |
| 48 | 8577896 | | Washer, Suspension Umbrella |
| 49 | 693995 | | Screw, Hex Head |
| 50 | W10341737 | | Led Assembly |
| 51 | 3391018 | | Tie Cable |

