


# Whirlpool WTW8600YW0 02 - CONTROL PANEL PARTS



Whirlpool [Residential Whirlpool WTW8600YW0 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10394233	<a href="#">W10447146</a>		Control Electric
2	<a href="#">W10130502</a>			Gasket, Valve Tray
3	<a href="#">8578550</a>			Tray Assembly, Console
4	<a href="#">8546616</a>			Gasket, Console/Tray
5	<a href="#">W10342320</a>			Valve, Log
6	<a href="#">W10211335</a>			Knob, Assembly
7	<a href="#">W10394243</a>			User Interface
8	<a href="#">8572039</a>			Seal, User Interface
9	<a href="#">W10404673</a>			Console
10	<a href="#">8564265</a>			Cover, Rear- User Interface
11	<a href="#">W10003770</a>			Screw, 6-19 X 1/2
12	<a href="#">W10022060</a>			Nut, Push-In
13	<a href="#">W10052600</a>			Screw, 8-18 X 3/4
14	<a href="#">8565324</a>			Screw, 10-16 X 1.75
15	<a href="#">8281136</a>			Screw, 10-16 X 3/4
16	<a href="#">W10435307</a>			Power Cord

17

[98460](#)

Nut, Push-In

18

[3351614](#)

Screw, Gearcase Cover  
Mounting

19

[W10404419](#)

Upper Harness

