


Whirlpool WTW8800YC0 02 - CONTROL PANEL PARTS



Whirlpool [Residential Whirlpool WTW8800YC0 Washer Parts](#) Parts Diagram 02 - CONTROL PANEL PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10394234	W10447147		Control Electric
2	W10130502			Gasket, Valve Tray
3	8578550			Tray Assembly, Console
"	W10309229			Tray Assembly, Console
4	8546616			Gasket, Console/Tray
5	W10342320			Valve, Log
6	W10211335			Knob, Assembly
7	W10394244			User Interface
9	W10404674			Console
"	W10404675			Console
10	8564265			Cover, Rear- User Interface
11	W10003770			Screw, 6-19 X 1/2
12	W10022060			Nut, Push-In
13	W10052600			Screw, 8-18 X 3/4
14	8565324			Screw, 10-16 X 1.75
15	8281136			Screw, 10-16 X 3/4

16	W10420367	Power Cord
17	98460	Nut, Push-In
18	3351614	Screw, Gearcase Cover Mounting
19	W10404420	Upper Harness
20	W10346406	Power Supply
21	9740849	Screw, 8-18 X 7/16

