


Whirlpool YGEW9250PL1 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)



8180932

7

Whirlpool [Residential Whirlpool YGEW9250PL1 Dryer Parts](#) Parts Diagram 04 - DOOR PARTS, OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	8563855			Label, Hinge Hole
2	8559709	280200		Hinge
3	342043	486146		Screw
4	9742177			Screw, 8-18 X .625
5	8529539			Bracket, Handle
7	8559739			Handle, Door Assembly
"	8559743			Handle, Door Assembly
"	8559738			Handle, Door Assembly Handle, Door Assembly
"	8559742			Handle, Door Assembly Handle, Door Assembly
8	3357011	308685		Side Trim)
9	8572960			Door Assembly
"	3980079	8572962		Door Assembly
10	8557501			Inner Door Assembly

11	355515		Screw, 8-18 X 11/16
12	3389441		Door Catch Assembly
14	8529540	8303811	Badge, Assembly
15	8528289		Filler Handle
"	3980082		Filler Handle
"	8528287		Filler Handle Filler Handle
"	3980101		Filler Handle Filler Handle
16	8559713		Cover-Hinge, Stationary
"	8559719		Cover-Hinge, Stationary
"	8559712		Cover-Hinge, Stationary Cover-Hinge, Stationary
"	8559718	Not Available	Cover-Hinge, Stationary (RH) (Following Parts Not Included) Cover-Hinge, Stationary (LH) (Pewter)
17	8559722		Cover-Hinge, Rotating
"	8559724		Cover-Hinge, Rotating
18	8547091	8181929	Clip, Trim
19	8558683	8533767	Trim And Clip Assembly
"	8558685	8533769	Trim And Clip Assembly
20	8558687	8529526	Trim And Clip Assembly
"	8558692	3980088	Trim And Clip Assembly
21	8558689	8529528	Trim And Clip Assembly
"	8558693	3980090	Trim And Clip Assembly
"	72017		Paint, Touch-Up
"	4396174		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	4396175		Paint, Pressurized Spray
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)
"	N/A	Not Available	ACCESSORY PARTS
"	8529894	346764	Kit, Hold Down
"	8541503		Kit, Stack Assembly
"	80047		PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	8530070		Kit, Door Reversing
"	8530072		Kit, Door Reversing

