


# Whirlpool YLEQ8000JQ2 02 - TOP AND CONSOLE PARTS



Whirlpool Residential Whirlpool YLEQ8000JQ2 Dryer Parts Parts Diagram 02 - TOP AND CONSOLE PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">8274261</a>			Do-It-Yourself Repair Manuals
2	<a href="#">3401684</a>			Jumper, Wire
3	<a href="#">693995</a>			Screw, Hex Head
4	8271365	<a href="#">279962</a>		Endcap
5	<a href="#">3400859</a>			Screw, Grounding
6	<a href="#">388326</a>			Screw, 8-18 X 1.25
7	<a href="#">694419</a>			Mini-Buzzer
8	8271359	<a href="#">279962</a>		Endcap
9	<a href="#">8528331</a>			Switch, Temperature
10	<a href="#">349639</a>			HANDLE AND LINT SCREEN ASSEMBLY
11	<a href="#">8283378</a>			Cover, Lint Screen
12	3978605	<a href="#">W10044470</a>		Hinge, RH
"	<a href="#">3978606</a>			Hinge, Lint Lid
13	688983	<a href="#">487240</a>		Screw, For Mtg. Service Capacitor
14	<a href="#">3347243</a>			Block, Disconnect

15	<a href="#">3395683</a>		Receptacle, Multi-Terminal
16	8271390	<a href="#">8521918</a>	Top
17	8271339	<a href="#">3957799</a>	Knob, Control
18	<a href="#">3394427</a>		Clip-Harness
19	<a href="#">3391249</a>		Cable Tie, Push Mount
20	<a href="#">3401144</a>		Connector
21	<a href="#">3406725</a>		Timer Assembly
22	<a href="#">3405154</a>		Switch Rotary
23	<a href="#">3397269</a>		Connector, Timer
24	<a href="#">94614</a>		Terminal
25	297535	<a href="#">17258</a>	Bumper
29	3390646	<a href="#">W10139210</a>	Screw, 8-18 X 5/16
30	<a href="#">357213</a>		Nut, Push-In
31	8299892	Not Available	Harness, Wiring
39	<a href="#">3398095</a>		Switch, Push-To-Start
48	8312687	<a href="#">3957754</a>	Timer Knob Assembly
50	<a href="#">3936144</a>		Do-It-Yourself Repair Manuals
51	3390537	<a href="#">8558178</a>	Control, Electronic
52	<a href="#">3391885</a>		Connector, Edge
53	<a href="#">8271418</a>		Bracket, Control
54	<a href="#">3977825</a>		Panel, Control
55	343641	<a href="#">681414</a>	Screw, 10AB X 1/2
"	BLANK	Not Available	ACCESSORY PARTS
"	279948	<a href="#">4392065</a>	Kit, Dryer Repair
"	<a href="#">3406839</a>		Dry Rack Assembly
"	<a href="#">72017</a>		Paint, Touch-Up
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )

