


Whirlpool YLER3624JQ1 02 - CABINET PARTS

CABINET PARTS

For Model: YLER3624JQ1
(Designer White)



4377965

3

Whirlpool [Residential Whirlpool YLER3624JQ1 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
2	694415			Clip, Strain Relief
3	3394208			Cord, Power
4	343641	681414		Screw, 10AB X 1/2
5	3394202		Not Available	Cover, Terminal Block
6	3396807	280040		Panel-Rear
7	694091			Trim, Side Right Hand
8	3406102			Door Switch Assembly
9	697773	3395530		Screw
10	693995			Screw, Hex Head
11	3392100	49621		Feet-Leveling
12	8530603	8533643		Cabinet
13	98234			Clip, U-Bend
14	690363	18776		Lock, Front Top
15	693197	280062		Panel
16	685203	279220		Clip
17	3389441			Door Catch Assembly

18	348023		Hinge And Pin Assembly
19	3394083		Clip, Front Panel
20	696144	279570	Latch
21	695656	280077	Door
22	348205		Door, Front
23	686711		Handle, Door
24	8066123	279264	Air Channel Box
25	279393		Terminal Block Screw Kit
27	238088	8066217	Hinge, Top
28	3394332	691366	Idler And Pulley Assembly
29	8066065	341241	Belt
30	348780		Base, Motor
31	3400500		Bolt, 3405245 5/16-18 X 3/4
32	3394341	W10299847	Pulley-Motor
33	661654	279827	Motor-Drve
34	660658		Clamp, Motor Mounting 343481 685441
35	3404162		Clamp, Motor
36	3390734		Seal, Door
37	697776	4331106	Screw, No.10-32 X 7/16
38	279318		Terminal Tinned And Brass Panel

