


Whirlpool YLER4634JQ2 02 - CABINET PARTS



8180362

3

Whirlpool [Residential Whirlpool YLER4634JQ2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
2	8541400			Bracket, Cabinet
3	694415			Clip, Strain Relief
5	3394202		Not Available	Cover, Terminal Block
6	3394208			Cord, Power
7	3396807	280040		Panel-Rear
8	3404413			Plug, Hinge Hole
9	342055	488627		Screw
10	3406104	3406105		Door Switch Assembly
11	697773	3395530		Screw
13	693995			Screw, Hex Head
14	3392100	49621		Feet-Leveling
"	279810			Foot-Optional
15	343641	681414		Screw, 10AB X 1/2
16	8530603	8533643		Cabinet
17	98234			Clip, U-Bend
18	690363	18776		Lock, Front Top

19	3403571	279844	Panel
20	685203	279220	Clip
21	690081	279570	Latch
22	3405514	W10362431	Hinge And Pin Assembly
23	3394083		Clip, Front Panel
24	696144	279570	Latch
25	3403371		Door, Inner
26	3403361		Door Front
27	3405184		Handle, Door
28	8066124	279264	Air Channel Box
31	238088	8066217	Hinge, Top
32	691366		Idler And Pulley Assembly
33	8066065	341241	Belt
34	348780		Base, Motor
35	3400500		Bolt, 3405245 5/16-18 X 3/4
36	3394341	W10299847	Pulley-Motor
37	8538262	279827	Motor-Drve
38	660658		Clamp, Motor Mounting 343481 685441
39	3404162		Clamp, Motor
40	3405245		5/16-18 X 3/4
41	697776	4331106	Screw, No.10-32 X 7/16

