


# Whirlpool YLER4634PQ0 01 - TOP AND CONSOLE PARTS



03-04 Litho in U.S.A. (dj)c

1

Part No. 8180279

Whirlpool Residential Whirlpool YLER4634PQ0 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	LIT3979614		Not Available	Literature Parts (Use & Care Guide)
"	LIT8533770		Not Available	Literature Parts (Sheet, Cycle Feature)
"	LIT8535831		Not Available	Literature Parts (Instructions, Installation)
"	LIT8535902		Not Available	Literature Parts (Label, Energy Guide)
"	LIT8528189		Not Available	Literature Parts (Label, Wiring Diagram)
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	LIT677818	<a href="#">677818L</a>		Diy
2	<a href="#">8274261</a>			Do-It-Yourself Repair Manuals
3	3390646	<a href="#">W10139210</a>		Screw, 8-18 X 5/16
4	8271365	<a href="#">279962</a>		Endcap
5	<a href="#">3936144</a>			Do-It-Yourself Repair Manuals
6	<a href="#">388326</a>			Screw, 8-18 X 1.25

7	<a href="#">3395683</a>		Receptacle, Multi-Terminal
8	8271359	<a href="#">279962</a>	Endcap
9	<a href="#">3400859</a>		Screw, Grounding
10	<a href="#">8557861</a>		Screen, Lint
11	<a href="#">8536939</a>		Clip, Knob
13	688983	<a href="#">487240</a>	Screw, For Mtg. Service Capacitor
15	<a href="#">693995</a>		Screw, Hex Head
16	8557930	<a href="#">8563985</a>	Top
17	<a href="#">3394427</a>		Clip-Harness
18	<a href="#">3391249</a>		Cable Tie, Push Mount
19	<a href="#">94614</a>		Terminal
21	<a href="#">8299778</a>		Timer, 60 Hz
22	<a href="#">357213</a>		Nut, Push-In
23	8299868	Not Available	Harness, Wiring
24	<a href="#">3977456</a>		Switch, Push-To-Start
25	<a href="#">8544955</a>		Timer Knob Assembly
26	<a href="#">8271418</a>		Bracket, Control
27	<a href="#">8545960</a>		Panel, Control
28	<a href="#">8544939</a>		Knob, Push-To-Start
"	BLANK	Not Available	ACCESSORY PARTS
"	279948	<a href="#">4392065</a>	Kit, Dryer Repair
"	<a href="#">689790</a>		Dry Rack
"	<a href="#">8522199</a>		Accessory Parts
"	<a href="#">72017</a>		Paint, Touch-Up
"	<a href="#">350930</a>		Paint, Pressurized Spray B
"	<a href="#">350938</a>		Paint, Pressurized Spray B
"	<a href="#">799344</a>		Paint, Touch-Up )

*the laundry company*<sup>®</sup>

*the laundry company*<sup>®</sup>