


**Whirlpool YLER8648PW1 03 - BULKHEAD PARTS, OPTIONAL PARTS
(NOT INCLUDED)**



8181076

5

Whirlpool [Residential Whirlpool YLER8648PW1 Dryer Parts](#) Parts Diagram 03 - BULKHEAD PARTS, OPTIONAL PARTS
(NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	348368			Lint Chute Assembly
2	487909	488729		Screw
3	3388703			Washer, Support
4	347139			Seal, Lint Chute
5	90767			Screw, 8A X 3/8 HeX Washer Head Tapping
6	696302			Shield, Exhaust
7	3392519			Thermal Limiter
8	3387134			Thermostat, Internal-Bias
9	3977393	279816		Cutoff-Tml
10	694089			Wheel, Blower
11	8577230			Housing, Blower
12	3398161			CLIP
13	343641	681414		Screw, 10AB X 1/2
14	8541818			Box, Heater

15	3977767		Thermostat, High Limit 250 F
16	3977373		Bracket, Drum Light
17	8576779	Not Available	Element, Heater (For 240 Volt Installation)
18	8066086		Plug, Drum Hole
19	279457		Wire Kit, Terminal
20	489463		Screw, 8-18 X 1/16
21	3390647	488729	Screw
33	3406124	22002263	Lamp
34	3402841	8532165	Lens, Drum Light
41	690997		Washer, Thrust
42	3399506	W10359270	Shaft, Drum Roller Threads
43	3399507	W10359269	Shaft, Drum Roller Threads
44	3397590	349241T	Support
46	348197		Washer, Support
47	3359452		Nut, Lock
48	3403413		Bulkhead
49	3403634	W10136369	Socket, Drum Light Assembly
62	692526	279441	BeaRng-Rng
63	97787	W10109200	Screw, Baffle Mounting
66	3406130	279857	Seal
67	695587		Drum Assembly
68	692490		Baffle, Drum
69	3976434		Bracket, Support Shaft
70	90296		Nut, Push On
71	3403636		Baffle, Drum
73	339956		Seal, Air Duct To Bulkhead
	BLANK	Not Available	ACCESSORY PARTS
"	279948	4392065	Kit, Dryer Repair
"	3406839		Dry Rack Assembly
"	8522199		Accessory Parts
"	72017		Paint, Touch-Up
"	350930		Paint, Pressurized Spray B
"	350938		Paint, Pressurized Spray B
"	799344		Paint, Touch-Up)

