


# Whirlpool YLEW0050PQ3 02 - CONTROL PANEL PARTS

## CONTROL PANEL PARTS

For Model: YLEW0050PQ3  
(White)



W10117254

3

Whirlpool Residential Whirlpool YLEW0050PQ3 Dryer Parts Parts Diagram 02 - CONTROL PANEL PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8182338	<a href="#">489355</a>		Screw, 8 X 1/2
2	<a href="#">280109</a>			Kit, Control Panel
4	<a href="#">280110</a>			Switch And Button Assembly
5	<a href="#">280112</a>			Switch And Button Assembly
6	<a href="#">8182522</a>			Timer And Indicator Light Assembly
7	<a href="#">8182575</a>			Button, Push
8	8182323	<a href="#">3179776</a>		Screw
9	<a href="#">8182361</a>			Spring, Knob
10	<a href="#">8182519</a>			Knob
11	<a href="#">8182532</a>			Lens, Indicator
12	<a href="#">280111</a>			Switch And Button Assembly