


Whirlpool YLTE5243DQ2 07 - WASHER CABINET PARTS

WASHER CABINET PARTS

For Model: YLTE5243DQ2
(Designer White)



4320099

9

Whirlpool [Residential Whirlpool YLTE5243DQ2 Washer/Dryer Parts](#) Parts Diagram 07 - WASHER CABINET PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	356746			Clip, Condenser
2	343641	681414		Screw, 10AB X 1/2
3	62863	3390631		Screw, 10-16 X 3/8
4	370451	596669		Clamp, Manifold
5	3360389	285805		Valve-Inlet
6	370445	285655		Clamp, Hose
7	692699			Hose, Water Inlet
8	696013			Cabinet
10	696710			Hose, Drain
11	692400			Nut, Push-In
12	660975			Plug, Top To Cabinet
13	356739	8557915		Connector, Hose
15	356471			Cap, Siphon Break
16	356363			Siphon Break
17	272861		Not Available	Clamp, Hose
18	696394			Hose, Water Inlet

21	660628	285655	Clamp, Hose
22	3394083		Clip, Front Panel
23	358652		Link, Leveling
24	359364		Clip, Leveling Mechanism
25	98234		Clip, U-Bend
26	345670		Lock, Top
27	692628		Panel, Front
28	367594		Foot, Front
29	358594		Foot, Rear
30	3400000		Screw, 10-24 X 3/8
32	3390046		Protector, Edge

