


# Whirlpool YLTE5243DQ7 03 - DRYER CABINET AND MOTOR PARTS

## DRYER CABINET AND MOTOR PARTS

For Model: YLTE5243DQ7  
(Designer White)



W10118209

3

Whirlpool Residential Whirlpool YLTE5243DQ7 Washer/Dryer Parts Diagram 03 - DRYER CABINET AND MOTOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
2	8538265	<a href="#">8539558</a>		Motor-Drive
5	<a href="#">696541</a>			Bracket, Motor
6	3390405	<a href="#">280069</a>		Panel
7	343641	<a href="#">681414</a>		Screw, 10AB X 1/2
8	<a href="#">3394228</a>			Cover, Terminal Block
9	<a href="#">90296</a>			Nut, Push On
10	<a href="#">3402293</a>			Panel, Side
14	<a href="#">3399602</a>			Elbow, Upper
15	<a href="#">3394083</a>			Clip, Front Panel
16	<a href="#">98234</a>			Clip, U-Bend
17	<a href="#">3399603</a>			Elbow, Lower
18	686770	<a href="#">686769</a>		Protector, Support
20	8066064	<a href="#">3394652</a>		Belt, Drive
21	<a href="#">8066051</a>			Pulley, Motor

22	<a href="#">691366</a>	Idler And Pulley Assembly
23	<a href="#">692771</a>	Nut, Idler Bracket To Base
24	<a href="#">3399632</a>	Base, Dryer
25	<a href="#">692400</a>	Nut, Push-In
26	<a href="#">692926</a>	Cove, Transition Panel
27	<a href="#">692933</a>	Panel, Transition
28	<a href="#">692641</a>	Top, Dryer
29	<a href="#">3402287</a>	Panel, Side
30	<a href="#">693145</a>	Latch, Lid
31	<a href="#">692781</a>	Closure, Control Area
32	<a href="#">354975</a>	Screw And Washer
33	<a href="#">693304</a>	Screw And Washer
34	697776	<a href="#">4331106</a> Screw, No.10-32 X 7/16
35	<a href="#">3390631</a>	Screw, 10-16 X 3/8
36	<a href="#">8572717</a>	Capacitor, Motor Start
37	<a href="#">357030</a>	Clamp, Capacitor

