


Whirlpool YLTE6234DQ4 03 - DRYER CABINET AND MOTOR PARTS



Whirlpool Residential Whirlpool YLTE6234DQ4 Washer/Dryer Parts Parts Diagram 03 - DRYER CABINET AND MOTOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	660658			Clamp, Motor Mounting 343481 685441
2	8538266	279811		Motor-Drve
3	3398948			Wire, Jumper
4	3394881	279782		Switch-Lid
5	3388858			Bracket, Motor
6	3389847	280039		Panel
7	343641	681414		Screw, 10AB X 1/2
8	3393717			Bracket, Spacer
10	3389264			Panel, Side
"	3389256			Panel, Side
11	687000			Strain-Relief
12	3393639		Not Available	Cord, Power Harness (3)
13	3393008	308685		Side Trim)
14	3394081			Wire, Broken Belt Switch
15	3389231			Clip, Front Panel

16	98234		Clip, U-Bend
17	3391639		Bracket, Bulkhead
18	233520		Washer, Thrust
19	690997		Washer, Thrust
20	3387610	661570	Belt
21	3391087	279811	Motor-Drive
22	3389332	3389331	Pulley, Idler
23	8533974	4331106	Screw, No.10-32 X 7/16
24	3390026		Base, Dryer
25	3387374		Spring, Idler
26	3389683		Cove, Transition Panel
27	3389272		Panel, Transition
28	3389537		Top, Dryer
30	3389682		Space-Toe Panel User-Interface
31	3393722		Bracket, Terminal Block
32	3389431		Bumper, Lid Stop
33	3390631		Screw, 10-16 X 3/8
34	3387485	273556	Screw, 10-16 X 5/8
35	98129		Screw, 6-20 X 1 1/16
36	3397659		Block, Terminal
38	3389420		Retainer-Idler 1/4-20 X 1/16
39	3388672	279640	Pulley-Idr
43	3394743	Not Available	Pin, Roll
44	692400		Nut, Push-In
47	693304		Screw And Washer
49	3390722		Shield, Console To Drum
50	279393		Terminal Block Screw Kit
51	279318		Terminal Tinned And Brass Panel
52	8066120		Lever, Door Switch

