


Whirlpool YRED4340SQ0 02 - CABINET PARTS



W10217548

3

Whirlpool [Residential Whirlpool YRED4340SQ0 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8541400			Bracket, Cabinet
2	3393008	308685		Side Trim)
3	3394208			Cord, Power
4	343641	681414		Screw, 10AB X 1/2
5	3394202		Not Available	Cover, Terminal Block
6	694415			Clip, Strain Relief
7	3396807	280040		Panel-Rear
8	342055	488627		Screw
9	3404413			Plug, Hinge Hole
10	3406104	3406105		Door Switch Assembly
11	697773	3395530		Screw
12	3400500			Bolt, 3405245 5/16-18 X 3/4
13	693995			Screw, Hex Head
14	8066184			Pulley, Motor
15	W10194250	279827		Motor-Drve
16	3392100	49621		Feet-Leveling

17	3405245		5/16-18 X 3/4
18	8530603	8533643	Cabinet
19	98234		Clip, U-Bend
20	690363	18776	Lock, Front Top
21	3403571	279844	Panel
22	279318		Terminal Tinned And Brass Panel
23	685203	279220	Clip
24	690081	279570	Latch
25	697776	4331106	Screw, No.10-32 X 7/16
26	3404162		Clamp, Motor
27	660658		Clamp, Motor Mounting 343481 685441
28	3405514	W10362431	Hinge And Pin Assembly
29	3394083		Clip, Front Panel
30	W10131364	341241	Belt
31	348780		Base, Motor
32	691366		Idler And Pulley Assembly
33	696144	279570	Latch
34	3403371		Door, Inner
35	3403361		Door Front
36	3405184		Handle, Door
37	8066124	279264	Air Channel Box
38	279393		Terminal Block Screw Kit
39	3397659		Block, Terminal
40	8066217		Hinge, Top

the laundry company[®]

the laundry company[®]