


Whirlpool YWED6400SW0 02 - TOP AND CONSOLE PARTS

TOP AND CONSOLE PARTS

For Model: YWED6400SW0
(White/Grey)



8181469

3

Whirlpool Residential Whirlpool YWED6400SW0 Dryer Parts Parts Diagram 02 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10106830	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
2	8558863			Bracket, Console
3	237446	487596		Washer
4	8563974			Assembly, User Interface
5	W10110325			Panel, Console
"	W10110330			Panel, Console
"	W10110328			Panel, Console
6	3196537	3196557		Panel, Manifold
7	8564265			Cover, Rear- User Interface
8	W10003770			Screw, 6-19 X 1/2
9	8574957			Knob, Assembly
10	8572270			Assembly, Lint Screen
11	W10044320	W10168227		Cover, Lint Screen
12	W10044470			Hinge, RH
"	W10044480			Hinge, L.H.
13	W10001580			Screw, 10-16 X 5/16

15	3395683		Receptacle, Multi-Terminal
16	8565025		Top
17	W10074270	W10111616	Control, Electronic
18	3394427		Clip-Harness
19	8563853		Bracket, Machine Controller
21	337686	Not Available	SCREW, 8-18 X .500
22	8558853		Screw, Grommet
23	W10076530	Not Available	Harness Wiring
25	3936144		Do-It-Yourself Repair Manuals
26	94614		Terminal
27	3397269		Connector, Timer

