


Whirlpool YWED6400SW1 01 - TOP AND CONSOLE PARTS



5-07 Litho in U.S.A. (L.T.)

1

Part No. W10123001 Rev. B

Whirlpool Residential Whirlpool YWED6400SW1 Dryer Parts Parts Diagram 01 - TOP AND CONSOLE PARTS
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10057300		Not Available	Tech Sheet
"	W10054090		Not Available	Guide, Quick Start
"	W10054070		Not Available	Use & Care Guide
"	BLANK		Not Available	Following May Be Purchased DO-IT-YOURSELF REPAIR MANUALS
"	677818		Not Available	Manual, Do-It- Yourself Repair (Dryer)
2	8558863			Bracket, Console
3	337686		Not Available	SCREW, 8-18 X .500
4	8563974			Assembly, User Interface
5	W10110325			Panel, Console
6	3196537	3196557		Panel, Manifold
7	8564265			Cover, Rear- User Interface
8	W10003770			Screw, 6-19 X 1/2
9	8574957			Knob, Assembly
10	8572270			Assembly, Lint Screen

11	W10044320	W10168227	Cover, Lint Screen
12	W10044470		Hinge, RH
"	W10044480		Hinge, L.H.
13	W10001580		Screw, 10-16 X 5/16
15	3395683		Receptacle, Multi-Terminal
16	8565025		Top
17	W10118243	W10111616	Control, Electronic
18	3394427		Clip-Harness
19	8563853		Bracket, Machine Controller
22	8558853		Screw, Grommet
23	W10111429	Not Available	Harness Wiring
25	3936144		Do-It-Yourself Repair Manuals
26	94614		Terminal
27	3397269		Connector, Timer

