



**NON – ILLUSTRATED  
PARTS**

*the laundry company*<sup>®</sup>

Includes

Optional Parts

Parts Not Included

Miscellaneous Parts



Whirlpool [Residential Whirlpool YWED9371YL0 Dryer Parts](#) Parts Diagram 05 - OPTIONAL PARTS (NOT INCLUDED)

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
NI	<a href="#">72017</a>			Paint, Touch-Up
"	<a href="#">W10268217</a>			Paint, Touch-Up
"	<a href="#">350930</a>			Paint, Pressurized Spray B
"	<a href="#">350938</a>			Paint, Pressurized Spray B
"	<a href="#">799344</a>			Paint, Touch-Up )
"	8529894	<a href="#">346764</a>		Kit, Hold Down
"	<a href="#">8522199</a>			Accessory Parts
"	80047			PAINT, BULK (1 QT.) (KIT, DRYER REPAIR)
"	<a href="#">8572546</a>			Odor Remover
"	<a href="#">PT220L</a>			Accessory Parts
"	<a href="#">PT400L</a>			Accessory Parts
"	<a href="#">PT600L</a>			Accessory Parts
"	W10206708	<a href="#">W10044609A</a>		Hose-Kit
"	<a href="#">89503</a>			Hose-Inlet
"	350027	<a href="#">49583</a>		Hose-Fill
				Washer Inlet-Hose

