


# Whirlpool YWED94HEXW2 01 - TOP AND CONSOLE PARTS



## TOP AND CONSOLE PARTS

For Models: YWED94HEXW2, YWED94HEXR2, YWED94HEXL2  
(White) (Red) (Lunar Silver)

27" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

5-12 Litho in U.S.A (GG)(bay)

1

Part No. W10505752 Rev. A

Whirlpool [Residential Whirlpool YWED94HEXW2 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305730		Not Available	USE & CARE GUIDE (ENGLISH)
"	W10420005		Not Available	TECH SHEET
"	W10423115		Not Available	INSTALLATION, INSTRUCTION
2	<a href="#">W10208383</a>			Top
"	<a href="#">W10337792</a>			Top
"	<a href="#">W10316282</a>			Top
3	W10441590		Not Available	TOP (HARNESS, MAIN)
4	<a href="#">W10464682</a>			Panel, Console
"	<a href="#">W10464684</a>			Panel, Console
"	<a href="#">W10464683</a>			Panel, Console
5	<a href="#">W10317570</a>			Water Channel
6	<a href="#">W10208198</a>			Bracket, Console
7	<a href="#">W10267938</a>			Harness, UI Jumper
8	<a href="#">W10267937</a>			Harness, Jumper
9	W10117943	<a href="#">8303811</a>		Badge, Assembly

10	<a href="#">693995</a>		Screw, Hex Head	
11	3390647	<a href="#">488729</a>	Screw	
12	W10450060		Not Available	CABLE, USER INTERFACE
13	<a href="#">W10317566</a>			Spring, Clip Water Channel
14	N/P		Not Available	KNOB, CONTROL
15	<a href="#">W10388441</a>			User Interface, Center

