


Whirlpool YWED97HEXW1 01 - TOP AND CONSOLE PARTS



TOP AND CONSOLE PARTS

For Models: YWED97HEXW1, YWED97HEXR1, YWED97HEXL1
(White) (Red) (Lunar Silver)

27" ELECTRIC DRYER



FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

7-11Litho in U.S.A. (JLP)(bay)

1

Part No. W10435617 Rev. A

Whirlpool [Residential Whirlpool YWED97HEXW1 Dryer Parts](#) Parts Diagram 01 - TOP AND CONSOLE PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	W10305728		Not Available	USE & CARE GUIDE
"	W10319757		Not Available	TECH SHEET
"	W10423115		Not Available	INSTALLATION, INSTRUCTION
2	W10208383			Top
"	W10337792			Top
"	W10316282			Top
3	W10357658		Not Available	HARNESS, MAIN
4	W10352483		Not Available	PANEL, CONSOLE ASSEMBLY (INCLUDE ITEMS, 7,8,9,10,13, 14,15 & 16) (WHITE)
"	W10352485			Panel, Console Assembly
"	W10352484			Panel, Console Assembly
5	W10317570			Water Channel
6	W10208198			Bracket, Console
7	W10267938			Harness, UI Jumper
8	W10267937			Harness, Jumper

9	W10117943	8303811	Badge, Assembly
10	693995		Screw, Hex Head
11	3390647	488729	Screw
12	W10267832		Cable, User Interface
13	W10317566		Spring, Clip Water Channel

