


Whirlpool YWED97HEXW1 04 - DOOR PARTS

DOOR PARTS

For Models: YWED97HEXW1 (White), YWED97HEXR1 (Red), YWED97HEXL1 (Lunar Silver)



W10435617

FOR ORDERING INFORMATION REFER TO PARTS PRICE LIST

7

Whirlpool Residential Whirlpool YWED97HEXW1 Dryer Parts Parts Diagram 04 - DOOR PARTS

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	W10208266			Door, Inner Assembly
2	W10208415			Hinge Base
3	W10208270			Door, Outer Screen
4	9742177			Screw, 8-18 X .625
5	W10208411			Handle, Door
6	W10208413			Cover, Door Switch
7	W10208271			Door, Trim Ring
8	W10208417			Window Inner Door
9	W10208268			Door Assembly (Outer) (Include Items, (3, 4, 5, 7 And 14)
10	W10267837			Door, Inner Assembly
11	W10288126			Screw, 10-32 X 1/2
12	W10208254			Door Inner Screw, 10-32 X 1/2
13	W10208252			Bracket, Glass
14	W10208269			Frame, Door Front Support
15	W10329710			Door Catch Assembly

