Maytag DG19CS 14 - 50HZ CONVERSION LIST



Maytag Residential Maytag DG19CS Dryer Parts Parts Diagram 14 - 50HZ CONVERSION LIST
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	Y014872			Screw, Coin Meter Stop -
002	NLA		Not Available	OUTER CASE (WHT)
003	NLA		Not Available	(ALM)
004	NLA		Not Available	(H. WHEAT)
005	211605			Bezel, Timer Dial
006	NLA		Not Available	TIMER (240-50)
007	Y304656		Not Available	MOTOR (240V 50HZ)
008	Y304697			BURNER ASSEMBLY
009	Y304698		Not Available	GAS VALVE (240-50)
010	NLA		Not Available	PILOT SHIELD ASSEMBLY
011	NLA		Not Available	COMBUSTION CONE
012	305186			Pulley, Motor
013	305186			Pulley, Motor
014	NLA		Not Available	MAIN WIRE HARNESS (240-50)
015	NLA		Not Available	PILOT LAMP
016	305812			Timer

017	306527	305812		Timer
018	Y310693		Not Available	COMPRESSION SLEEVE
019	Y311711			Screw, Fuse Block
020	NLA		Not Available	AIR SHUTTER
021	Y312483			PILOT TUBE
022	NLA		Not Available	GAS CONTROL BRACKET
023	NLA		Not Available	GAS BURNER INSTRUCT LABEL

the laundry company®
the laundry company®
the laundry company®