Maytag PYET344AYW 02 - CONTROL PANEL



Maytag Residential Maytag PYET344AYW Dryer Parts Parts Diagram 02 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	31001549			Panel, Control
2	21001519			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
3	21001523			Endcap
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
4	53-1639			Buzzer Assembly
5	31001550	37001184		Timer Knob And Skirt Assembly
6	31001190			Switch, Two Position Rotary
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
7	21002005			Frame, Control Panel
8	21001527			Shield, Rear
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
9	31001484			Resistor Assembly

"	31001513			Timer
"	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
10	21001603			Shield, Control
"	31001193			Pad, Shield
11	21001954			Knob, Selector
12	25-3092	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	31001447			Switch, Temperature
"	31001483			Resistor Assembly Temperature
"	53-4395			Switch, Temperature
"	31001704			Resistor Assembly Temperature
13	22003977	74010226		Switch, Rocker W/Shield
14	21001978			Lead Assembly
"	31001557			Lead Assembly
"	31001559		Not Available	LEAD ASSEMBLY (BUZZER)
"	53-4450			Harness, Wiring
"	31001488			Harness, Wire

the laundry company®
the laundry company®
the laundry company®