Whirlpool WTW6300SB2 03 - MOTOR, BASKET AND TUB PARTS



Whirlpool Residential Whirlpool WTW6300SB2 Washer Parts Parts Diagram 03 - MOTOR, BASKET AND TUB PARTS
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	8566491			Dispenser, Fabric Softener
2	W10076270			Screw And Washer Assembly
3	W10076260			Washer
4	W10108420	W10130806		Tub Ring
5	8572540	353244		Hose, Pressure Switch
6	W10076190			Agitator
7	8533953			Screw, 8-16 X 1.000
8	W10118114	280145		Hub
9	8545953	280145		Hub
10	W10118180	W10321522		Basket
11	8572660	W10193886		Tub-Outer
12	8577284			Auger, Agitator
13	8542674			Weight, Tub Counterbalance
14	W10004910			Screw, 12-16 X 1-1/4
15	8557839	W10137698		Shield, Drive Motor
16	8565172	280142		Tube

17	8565170	W10419333		Stator, Motor
18	8557836			Plate, Stator
19	W10076010	8534042		Screw, 1/4-20 X .968
20	8565188	W10183157		Kit
21	8565177	280146		Rotor
22	BLANK		Not Available	Bolt, Rotor Assembly Non-Serviceable (Supplied W/Rotor)
23	W10058730	W10183157		Kit
24	8566197	W10222008		Filter, Dual Pump Hood
25	8533928			Screw, 8-18 X 3/4
26	8566279			Spacer-Thrust
27	W10005430			Clamp, Pressure Hose Retainer
28	8533957			Screw, 10-16 X 1/2
29	W10076310			Agitator, Assembly
30	W10074580			Cap, Barrier
31	W10072840			Fabric Softener
32	W10076210	280174		Cam-Agitator
33	8558884	280160		Roller
34	8578563			Spacer, Thrust-Cam

the laundry company®
the laundry company®