


# Whirlpool CEM2760KQ2 02 - CABINET PARTS



Whirlpool [Commercial Whirlpool CEM2760KQ2 Dryer Parts](#) Parts Diagram 02 - CABINET PARTS  
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	3393008	<a href="#">308685</a>		Side Trim )
2	<a href="#">3353948</a>			Bracket, Lock
3	<a href="#">3391846</a>			Clip, Front Panel
4	3393258	<a href="#">3373329D</a>		Screw
5	3394881	<a href="#">279782</a>		Switch-Lid
6	<a href="#">3397659</a>			Block, Terminal
7	<a href="#">8310656</a>			Cabinet
8	3392100	<a href="#">49621</a>		Feet-Leveling
"	<a href="#">279810</a>			Foot-Optional
9	<a href="#">660658</a>			Clamp, Motor Mounting 343481 685441
10	<a href="#">3387374</a>			Spring, Idler
11	<a href="#">3389420</a>			Retainer-Idler 1/4-20 X 1/16
12	697750	<a href="#">W10470674</a>		Dryer Exhaust Kit
13	3388672	<a href="#">279640</a>		Pulley-ldr
14	3391915	<a href="#">681615</a>		Screw
15	<a href="#">3394331</a>			Plate Cover

16	<a href="#">3394081</a>		Wire, Broken Belt Switch
17	<a href="#">356674</a>		Cone, Wedge
18	<a href="#">233520</a>		Washer, Thrust
19	<a href="#">297092</a>		Clip
20	<a href="#">690997</a>		Washer, Thrust
21	<a href="#">3389247</a>		Hinge And Pin Assembly
22	<a href="#">63554</a>		Rivet
23	<a href="#">3391943</a>		Boot, Foot
25	697773	<a href="#">3395530</a>	Screw
26	<a href="#">3389249</a>		Nut, Inner Door
27	8538264	<a href="#">W10438970</a>	Motor-Drve
28	3389627	<a href="#">W10299847</a>	Pulley-Motor
30	3387610	<a href="#">661570</a>	Belt
31	<a href="#">3390902</a>		Clip, Door Hinge
32	<a href="#">3387118</a>		Bracket, Motor
33	3392186	<a href="#">4159590</a>	Washer
34	<a href="#">279318</a>		Terminal Tinned And Brass Panel
35	<a href="#">279393</a>		Terminal Block Screw Kit
36	3390663	<a href="#">681414</a>	Screw, 10AB X 1/2
37	697776	<a href="#">4331106</a>	Screw, No.10-32 X 7/16
39	3388674	<a href="#">W10118756</a>	Idler Bracket
40	<a href="#">3388600</a>		Clip, Lint Duct
41	3406109	<a href="#">3406107</a>	Door Switch Assembly
42	<a href="#">98129</a>		Screw, 6-20 X 1 1/16
44	<a href="#">3387242</a>		Seal, Front Panel
45	342055	<a href="#">488627</a>	Screw
46	<a href="#">3388229</a>		Retainer, Toe Panel
47	3392563	<a href="#">280083</a>	Door-Rear
48	<a href="#">694091</a>		Trim, Side Right Hand
49	<a href="#">3387872</a>		Door, Front
51	3393081	<a href="#">279722</a>	Panel
52	696144	<a href="#">279570</a>	Latch
55	<a href="#">693995</a>		Screw, Hex Head
57	<a href="#">3390735</a>		Seal, Door
58	3392538	<a href="#">279570</a>	Latch
59	<a href="#">3398948</a>		Wire, Jumper
60	<a href="#">3389522</a>		Handle, Door
61	697215	<a href="#">3406797</a>	Toe Panel
62	<a href="#">3393657</a>		Restrainer, Belt
64	<a href="#">8066120</a>		Lever, Door Switch
65	279731	<a href="#">49026</a>	4" - 90° Elbow
66	279818	<a href="#">W10470674</a>	Dryer Exhaust Kit