


Amana CW4202W2 (BOM: PCW4202W2A) 15 - OUT-OF-BALANCE SWITCH



W2402W2A

Amana Residential Amana CW4202W2 (BOM: PCW4202W2A) Washer Parts Parts Diagram 15 - OUT-OF-BALANCE SWITCH

[Click on the part number to view part](#)

Item	Original Part Number	Replaced By	Status	Part Description
1	34902_P		Not Available	CABINET TOP
2	33445	27001095		Switch, Lid
3	36510			Screw
4	36497P			Kit, Switch Holder
5	33441			Arm, Actuator
6	33442			Lever, Unbalanced Load
7	33443			Spring
8	23962	W10116760		Screw