


Amana LW7503L2 (BOM: PLW7503L2 A) 10 - GRAPHIC PANEL, CTRL MTG PLATE AND CTRLS



Amana Residential Amana LW7503L2 (BOM: PLW7503L2 A) Washer Parts Parts Diagram 10 - GRAPHIC PANEL, CTRL
MTG PLATE AND CTRLS
Click on the part number to view part

| Item | Original Part Number | Replaced By | Status | Part Description |
|------|----------------------|---------------------------|---------------|-----------------------------------------|
| 1 | Y34826 | | Not Available | DIFFUSER,LAMP-CLEAR |
| 2 | 34824 | | Not Available | TOP COVER |
| 3 | 23962 | W10116760 | | Screw |
| 4 | 34904 | 489355 | | Screw, 8 X 1/2 |
| 5 | 31239 | 31239P | | Timer 3 Cycle Package |
| 6 | 501086 | 90767 | | Screw, 8A X 3/8 HeX Washer Head Tapping |
| 7 | 34817 | | Not Available | END CAP(RIGHT) |
| 8 | 34903 | | Not Available | PANEL, BACK HOOD (USE 37782) |
| 9 | 34902P | | Not Available | TOP |
| 10 | 34821 | | Not Available | CONTROL MOUNTING PLATE |
| 11 | 38106 | | Not Available | PANEL, GRAPHICS |
| " | 37681W | | Not Available | PANEL, GRAPHICS (WHITE) |
| " | 36613 | | Not Available | GRAPHIC PANEL |

| | | | |
|----|-----------------------|-----------------------|-------------------------|
| 12 | 36700 | Not Available | TIMER KNOB SKIRT |
| 13 | 35333 | Not Available | TIMER KNOB |
| 14 | 36701 | Not Available | KNOB, TEMP |
| 15 | 34818 | Not Available | END CAP(LEFT) |
| 16 | 35115 | | Switch, TemPerature 3 P |
| 17 | 35010 | 39035 | Switch, Pressure-Var |

