



Maytag DG7600 01 - CONTROL PANEL

SECTION: CONTROL PANEL
MODEL: DE-DG7600



Issue Date: 6/90

12

Maytag [Residential Maytag DG7600 Dryer Parts](#) Parts Diagram 01 - CONTROL PANEL
Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
1	314184			Back Up Plate
2	214872			Palnut, End Cap Note: Nut, Lamp Holder
3	211168	W10139210		Screw, 8-18 X 5/16
"	307305			Switch Push To Start
4	306917			Resistor, Med Temp Gas
5	213117	67006908		Screw, Ice Rack
"	307304		Not Available	TEMP CONTROL SWITCH 3 BUTTON
6	305205	694419		Mini-Buzzer
"	211168	W10139210		Screw, 8-18 X 5/16
7	211294	90767		Screw, 8A X 3/8 HeX Washer Head Tapping
"	204807			Ground Wire, Supp. Plte To Top Cover
8	305448			Timer
"	910708	488234		Screw 8-32 X 1/4
9	214897			Pad, Control Panel

10	210932		Screw, No.8 X 9/16 Ctsk Note: Screw, Inlet Duct
"	207216	Not Available	END CAP RH
11	214894		Fastener, End Cap
12	215821	Not Available	CAP, KNOB
13	312273		Nut, Control Knob
14	315041		Knob, Timer
15	315042		Dial Skirt
16	307317	Not Available	CONTROL PANEL
17	307281	Not Available	WIRE HARNESS
18	207215	Not Available	END CAP LH

