


# Maytag MAH14PDSAW 02 - CONTROL CENTER (PD)



\* CONTACT YOUR COMMERCIAL LAUNDRY DISTRIBUTOR

Maytag [Residential Maytag MAH14PDSAW Washer Parts](#) Parts Diagram 02 - CONTROL CENTER (PD)  
 Click on the part number to view part

Item	Original Part Number	Replaced By	Status	Part Description
001	<a href="#">22002480</a>			Vault, Coin PD Coin Drop Supplied By Dist.
002	22001810		Not Available	STRAP, MOUNTING
003	22001996	<a href="#">3370225</a>		Screw
004	<a href="#">910309</a>			Washer, Mounting Strap
005	<a href="#">22002072</a>			Gasket, Control Center
006	Y052740	<a href="#">62739</a>		Nut, Lock
007	<a href="#">213035</a>			Bolt, Locking
008	<a href="#">910181</a>			Lockwasher, Terminal Block
009	NLA		Not Available	CAM, LOCKING
010	<a href="#">22002536</a>			Switch, Sensor
"	912012	<a href="#">3400409</a>		Screw
011	22001873	<a href="#">22004112</a>		Coin Drop Greenwald Us.25
"	<a href="#">22002144</a>			Single Faceplate
012	<a href="#">216200</a>			Face Plate Return Button
013	22001910	<a href="#">22003679</a>		Timer Access Door Assembly
014	<a href="#">22001965</a>			Optic Switch Assembly

015	<a href="#">314665</a>	Screw, Switch Assembly
016	<a href="#">216068</a>	Screw, Coin Drop
017	<a href="#">22001404</a>	Bracket, Service Switch
018	<a href="#">22001069</a>	Screw, Vault To Control Cover
019	<a href="#">22001966</a>	Harness, Sensor Switch

